

WHITEPRINT MAINTENANCE

The white ink behaves a little differently compared to the CMYK inks. Therefore, it is important that you mix the ink in the ink bag once a week and clean the nozzle properly.

MIXING THE COLOUR

To mix, place the flat of your hand on the ink bag with your fingers spread to gently knead the ink bag in gentle undulating motions.

Nevertheless, we recommend that you do this before each print.

It is a good idea to combine this with venting.





To clean the nozzle, you need the Flushing and 3 Dust Free Wipes. Moisten two Dust Free Wipes with the flushing and wipe carefully and without pressure in one direction over the nozzle.

Then you can carefully wipe it dry with a dry Dust Free Wipe, in one direction.